


STEP 1: Company information

COMPANY:	CUSTOMER NAME:
DIST. CENTER ADDRESS:	
MEASURED BY:	DATE:
PHONE:	FAX:
NOTES:	

STEP 2: Truck information

UNIT #:	LIC. #:
VIN #:	
MAKE:	YEAR BUILT:
TRUCK SIZE: <input type="text"/> Ft.	Back door: <input type="checkbox"/> SWING <input type="checkbox"/> ROLL UP
Truck has ribs <input type="checkbox"/> Y <input type="checkbox"/> N	...or corrugations <input type="checkbox"/> Y <input type="checkbox"/> N
Flat aluminum <input type="checkbox"/> Y <input type="checkbox"/> N	Bull-nose <input type="checkbox"/> Y <input type="checkbox"/> N
Has reflectors <input type="checkbox"/> Y <input type="checkbox"/> N	...or hazmat signs <input type="checkbox"/> Y <input type="checkbox"/> N
Damaged driver, <input type="checkbox"/> Y <input type="checkbox"/> N	...or curb side <input type="checkbox"/> Y <input type="checkbox"/> N

STEP 4: Physically take all measurements 1 - 8, and complete in FEET, INCHES and FRACTIONS! CRITICAL: Specify to the 1/8 of an inch.



Draw and describe any hardware or damage that may interfere with the installation.